

## 0601

Function Location	Description	Hours
0601	KOMATSU HD785 HAUL TRUCK	16240.46
0601-24VELEC	24 VOLT ELECTRICAL SYSTEM	16240.46
0601-HYDRSYS-CNTGRP-VALVEHYD	HOIST VALVE	16240.46
0601-HYDRSYS-CYLNDR-CYLINDERHOIST/LT	HOIST CYLINDER LEFT	16240.46
0601-HYDRSYS-CYLNDR-CYLINDERHOIST/RT	HOIST CYLINDER RIGHT	16240.46
0601-HYDRSYS-PMPDRV-GEARBOX	PUMP DRIVE GEARBOX	16240.46
0601-HYDRSYS-PMPHYD-PUMPAUX	HOIST PUMP AUXILLIARY	16240.46
0601-HYDRSYS-PMPHYD-PUMPMAIN	HOIST PUMP MAIN	16240.46
0601-OPTIONS-BODYGP-DUMPBODY	DUMP BODY	16240.46
0601-OPTIONS-FIRESU	FIRE SUPPRESSION SYSTEM	16240.46
0601-OPTIONS-LUBSYS	GREASE SYSTEM	16240.46
0601-POWRTRN-DIFFNL-DIFFERENTIAL	DIFFERENTIAL	16240.46
0601-POWRTRN-DRVSFT-DRIVESHAFT/FT	FRONT DRIVE SHAFT	16240.46
0601-POWRTRN-DRVSFT-DRIVESHAFT/RE	REAR DRIVE SHAFT	16240.46
0601-POWRTRN-ENGSYS-ENGINE	ENGINE	16240.46
0601-POWRTRN-ENGSYS-RADIATOR	RADIATOR	16240.46
0601-POWRTRN-FNLDRV-FINALDRIVE/LT	LEFT FINAL DRIVE	16240.46
0601-POWRTRN-FNLDRV-FINALDRIVE/RT	RIGHT FINAL DRIVE	16240.46
0601-POWRTRN-TORQUE-TORQUECONVERTOR	TORQUE CONVERTOR	16240.46
0601-POWRTRN-TRANSM-TRANSMISSION	TRANSMISSION	16240.46
0601-STRUCTR-AXLGR-BEARING	NOSE CONE BEARING	16240.46
0601-STRUCTR-CABGRP-CABHVAC	AIR CONDITIONING SYSTEM	16240.46
0601-STRUCTR-FRAMGP	FRAME GROUP	16240.46
0601-WHEELST-AXLEGRE-HOUSING	REAR AXLE HOUSING	16240.46
0601-WHEELST-FRNTWH-STRUT/LF	LEFT FRONT SUSPENSION STRUT	16240.46
0601-WHEELST-FRNTWH-STRUT/LF	RIGHT FRONT SUSPENSION STRUT	16240.46
0601-WHEELST-REARWH-STRUT/LR	LEFT REAR SUSPENSION STRUT	16240.46
0601-WHEELST-REARWH-STRUT/RR	RIGHT REAR SUSPENSION STRUT	16240.46
0601-WHEELST-STRGGP-CYLINDERSTRG/LT	STEERING CYLINDER LEFT	16240.46
0601-WHEELST-STRGGP-CYLINDERSTRG/RT	STEERING CYLINDER RIGHT	16240.46
0601-WHEELST-STRGGP-PUMP	STEERING PUMP	16240.46

## 0602

Function Location	Description	Hours
0602	KOMATSU HD785 HAUL TRUCK	15105.78
0602-24VELEC	24 VOLT ELECTRICAL SYSTEM	15105.78
0602-HYDRSYS-CNTGRP-VALVEHYD	HOIST VALVE	15105.78
0602-HYDRSYS-CYLNDR-CYLINDERHOIST/LT	HOIST CYLINDER LEFT	15105.78
0602-HYDRSYS-CYLNDR-CYLINDERHOIST/RT	HOIST CYLINDER RIGHT	15105.78
0602-HYDRSYS-PMPDRV-GEARBOX	PUMP DRIVE GEARBOX	15105.78
0602-HYDRSYS-PMPHYD-PUMPAUX	HOIST PUMP AUXILLIARY	15105.78
0602-HYDRSYS-PMPHYD-PUMPMAIN	HOIST PUMP MAIN	15105.78
0602-OPTIONS-BODYGP-DUMPBODY	DUMP BODY	15105.78
0602-OPTIONS-FIRESU	FIRE SUPPRESSION SYSTEM	15105.78
0602-OPTIONS-LUBSYS	GREASE SYSTEM	15105.78
0602-POWRTRN-DIFFNL-DIFFERENTIAL	DIFFERENTIAL	15105.78
0602-POWRTRN-DRVSFT-DRIVESHAFT/FT	FRONT DRIVE SHAFT	15105.78
0602-POWRTRN-DRVSFT-DRIVESHAFT/RE	REAR DRIVE SHAFT	15105.78

0602-POWRTRN-ENGSYS-ENGINE	ENGINE	15105.78
0602-POWRTRN-ENGSYS-RADIATOR	RADIATOR	15105.78
0602-POWRTRN-FNLDRV-FINALDRIVE/LT	LEFT FINAL DRIVE	15105.78
0602-POWRTRN-FNLDRV-FINALDRIVE/RT	RIGHT FINAL DRIVE	15105.78
0602-POWRTRN-TORQUE-TORQUECONVERTOR	TORQUE CONVERTOR	15105.78
0602-POWRTRN-TRANSM-TRANSMISSION	TRANSMISSION	1990.73
0602-STRUCTR-AXLGR-BEARING	NOSE CONE BEARING	15105.78
0602-STRUCTR-CABGRP-CABHVAC	AIR CONDITIONING SYSTEM	15105.78
0602-STRUCTR-FRAMGP	FRAME GROUP	15105.78
0602-WHEELST-AXLEGRE-HOUSING	REAR AXLE HOUSING	15105.78
0602-WHEELST-FRNTWH-STRUT/LF	LEFT FRONT SUSPENSION STRUT	15105.78
0602-WHEELST-FRNTWH-STRUT/LF	RIGHT FRONT SUSPENSION STRUT	15105.78
0602-WHEELST-REARWH-STRUT/LR	LEFT REAR SUSPENSION STRUT	15105.78
0602-WHEELST-REARWH-STRUT/RR	RIGHT REAR SUSPENSION STRUT	15105.78
0602-WHEELST-STRGGP-CYLINDERSTRG/LT	STEERING CYLINDER LEFT	15105.78
0602-WHEELST-STRGGP-CYLINDERSTRG/RT	STEERING CYLINDER RIGHT	15105.78
0602-WHEELST-STRGGP-PUMP	STEERING PUMP	15105.78

## 0603

Function Location	Description	Hours
0603	KOMATSU HD785 HAUL TRUCK	16266.63
0603-24VELEC	24 VOLT ELECTRICAL SYSTEM	16266.63
0603-HYDRSYS-CNTGRP-VALVEHYD	HOIST VALVE	16266.63
0603-HYDRSYS-CYLNDR-CYLINDERHOIST/LT	HOIST CYLINDER LEFT	16266.63
0603-HYDRSYS-CYLNDR-CYLINDERHOIST/RT	HOIST CYLINDER RIGHT	16266.63
0603-HYDRSYS-PMPDRV-GEARBOX	PUMP DRIVE GEARBOX	16266.63
0603-HYDRSYS-PMPHYD-PUMPAUX	HOIST PUMP AUXILLIARY	16266.63
0603-HYDRSYS-PMPHYD-PUMPMAIN	HOIST PUMP MAIN	519.36
0603-OPTIONS-BODYGP-DUMPBODY	DUMP BODY	16266.63
0603-OPTIONS-FIRESU	FIRE SUPPRESSION SYSTEM	16266.63
0603-OPTIONS-LUBSYS	GREASE SYSTEM	16266.63
0603-POWRTRN-DIFFNL-DIFFERENTIAL	DIFFERENTIAL	16266.63
0603-POWRTRN-DRVSFT-DRIVESHAFT/FT	FRONT DRIVE SHAFT	16266.63
0603-POWRTRN-DRVSFT-DRIVESHAFT/RE	REAR DRIVE SHAFT	16266.63
0603-POWRTRN-ENGSYS-ENGINE	ENGINE	16266.63
0603-POWRTRN-ENGSYS-RADIATOR	RADIATOR	16266.63
0603-POWRTRN-FNLDRV-FINALDRIVE/LT	LEFT FINAL DRIVE	16266.63
0603-POWRTRN-FNLDRV-FINALDRIVE/RT	RIGHT FINAL DRIVE	16266.63
0603-POWRTRN-TORQUE-TORQUECONVERTOR	TORQUE CONVERTOR	16266.63
0603-POWRTRN-TRANSM-TRANSMISSION	TRANSMISSION	16266.63
0603-STRUCTR-AXLGR-BEARING	NOSE CONE BEARING	16266.63
0603-STRUCTR-CABGRP-CABHVAC	AIR CONDITIONING SYSTEM	16266.63
0603-STRUCTR-FRAMGP	FRAME GROUP	16266.63
0603-WHEELST-AXLEGRE-HOUSING	REAR AXLE HOUSING	16266.63
0603-WHEELST-FRNTWH-STRUT/LF	LEFT FRONT SUSPENSION STRUT	16266.63
0603-WHEELST-FRNTWH-STRUT/LF	RIGHT FRONT SUSPENSION STRUT	16266.63
0603-WHEELST-REARWH-STRUT/LR	LEFT REAR SUSPENSION STRUT	16266.63
0603-WHEELST-REARWH-STRUT/RR	RIGHT REAR SUSPENSION STRUT	16266.63
0603-WHEELST-STRGGP-CYLINDERSTRG/LT	STEERING CYLINDER LEFT	16266.63
0603-WHEELST-STRGGP-CYLINDERSTRG/RT	STEERING CYLINDER RIGHT	1935.63
0603-WHEELST-STRGGP-PUMP	STEERING PUMP	519.36